



AHU-400 BV og BH




- N** Koblings skjema
- GB** Wiring diagram

Produsent/Manufacturer:



Forhandler/Distributer:



- N Koblings skjema**
- W = Hvit
 - BR = Brun
 - Y = Gul
 - Y/GR = Gul/grønn
 - B = Blå
 - BL = Sort
 - G = Grå
 - R = Rød
 - AT = Arbeidstemperatur sensor
 - EAT = Avtrekktemperatur sensor
 - OET = Overhetingstemperatur sensor
 - UTE = Friskluft temperatur sensor// Avrimingsensor
 - AVK = Rotorvakt
 - TV = Tilluftvifte
 - AV = Avtrekksvifte
 - MCC = Drossel
 - EV = Ettervarmebatter
 - RO = Rotormotor
 - BT = Branntermostat
 - B1 = Bryter for å slå av fuktighetsføler
 - KV = Kjøkkenhette (Tilbehør)
 - CO² = CO² Sensor (Tilbehør)
 - D¹ = Impuls bryter (Tilbehør)
 - D² = (Tilbehør)
 - D³ = Hjemme / Borte (Tilbehør)
- GB Wiring diagram**
- W = White
 - BR = Brown
 - Y = Yellow
 - Y/GR = Yellow/green
 - B = Blue
 - BL = Black
 - G = Grey
 - R = Red
 - AT = Operation temperature sensor
 - EAT = Extract air sensor
 - OET = Overheat temperature sensor
 - UTE = Fresh air sensor/ Defrost sensor
 - AVK = Rotor guard
 - TV = Inlet fan
 - AV = Extract fan
 - MCC = I core choke
 - EV = Reheater battery
 - RO = Rotor motor
 - BT = Fire thermostat
 - B1 = Switch to turn off humidity sensor
 - KV = Cookerhood (Option)
 - CO² = CO² Sensor (Option)
 - D¹ = Impulse switch (Option)
 - D² = (Option)
 - D³ = Home / Leave (Option)